

PPC-S154 Wall Mount Kit Setup Guide

The PPC-S154's customized wall mount kit is designed to mount your panel PC perfectly on the wall. Your wall mount kit should contain one of each of the following:

- wall mount plate
- setup guide
- packet of screws

Follow these procedures to wall-mount your panel PC:

1. First, attach the VESA-standard bracket which comes with the accessory box with panel PC by screwing the six screws..
2. Drill six holes into the wall. Use a hammer to drive in the anchors up to the whole anchors inside the holes on the wall.
3. Screw the wall mount plate with six of the provided screws
4. Put the panel PC with VESA-standard bracket against the wall mount plate.
5. To attach it on the wall, align the four holes located at the corner of the VESA-standard bracket to the four protrusions on the wall mount plate.
6. To prevent the panel PC from any accidental fall or dislocation, you can tighten the screws labelled A on the diagram.

