

# Square D® 9001 BW Pendant Station

Robust BW pendant performance with the added convenience of internal strain relief.



Perfect for simple applications that require control units that are specifically designed for hoisting applications, the Square D® 9001 BW pendant station is a pre-assembled, two-button station that's recognized for its sturdiness and resistance to both mechanical shocks and chemical agents.

Oversized finger grips on the rear of the enclosure make it easy to grip and operate and include internal strain relief as a standard option. Enclosures are available in three colors, and for convenience, push buttons have interchangeable legend inserts. All universal stations have double circuit blocks (1 N.O. / 1 N.C.) on each button and come without legends so they can be assembled to fit the application.

Schneider Electric, a world leader in control and signaling components, continues to provide innovative and efficient operator interface solutions with the Harmony range of push buttons.

## > Key Features:

- Easy to hold in one hand with contoured grip
- Single-speed or two-speed buttons
- Momentary or maintained contact
- Available with or without mechanical interlocks
- Yellow, black or red enclosure options
- High impact thermoplastic enclosure with self-extinguishing flammability rating (UL 94V)
- NEMA 1, 3, 3R, 4, 4X and 13 water-tight, dust-tight, oil-tight and corrosion-resistant
- UL listed, CSA approved, carries CE marking

Make the most of your energy<sup>SM</sup>

**Schneider**  
Electric

# Square D® 9001 BW Pendant Station

## BW90 and BW100 Pendant Stations with Strain Relief

| Description  | Legend Insert Markings | Mechanical Interlock | Enclosure Color |         |         |
|--------------|------------------------|----------------------|-----------------|---------|---------|
|              |                        |                      | Yellow          | Black   | Red     |
| Single Speed | Up-Down                | Yes                  | BW92Y           | BW92B   | BW92R   |
|              | Forward-Reverse        | Yes                  | BW93Y           | BW93B   | BW93R   |
|              | On-Off•                | Yes                  | BW94Y           | BW94B   | BW94R   |
|              | Start-Stop             | No                   | BW95Y           | BW95B   | BW95R   |
|              | Start-Stop•            | Yes                  | BW96Y           | BW96B   | BW96R   |
|              | On-Off•                | No                   | BW97Y           | BW97B   | BW97R   |
|              | Up-Down                | Yes                  | BW98Y           | BW98B   | -       |
|              | Without Inserts        | Yes                  | BW90YU          | BW90BU  | BW90RU  |
|              | Without Inserts        | No                   | BW91YU          | BW91BU  | BW91RU  |
| Two Speed    | Without Inserts•       | Yes                  | BW94YU          | BW94BU  | BW94RU  |
|              | Without Inserts        | Yes                  | BW100YU         | BW100BU | BW100RU |
|              | Up-Down                | Yes                  | BW102Y          | BW102B  | BW102R  |

• Maintained Contact

## BW70 and BW80 Pendant Stations

| Description  | Legend Insert Markings | Mechanical Interlock | Enclosure Color |        |        |
|--------------|------------------------|----------------------|-----------------|--------|--------|
|              |                        |                      | Yellow          | Black  | Red    |
| Single Speed | Up-Down                | Yes                  | BW72Y           | BW72B  | BW72R  |
|              | Forward-Reverse        | Yes                  | BW73Y           | BW73B  | BW73R  |
|              | On-Off•                | Yes                  | BW74Y           | BW74B  | BW74R  |
|              | Start-Stop             | No                   | BW75Y           | BW75B  | BW75R  |
|              | Start-Stop•            | Yes                  | BW76Y           | BW76B  | BW76R  |
|              | On-Off•                | No                   | BW77Y           | BW77B  | BW77R  |
|              | Up-Down                | Yes                  | BW78Y           | BW78BY | -      |
|              | Without Inserts        | Yes                  | BW70YU          | BW70BU | BW70RU |
|              | Without Inserts        | No                   | BW71YU          | BW71BU | BW71RU |
| Two Speed    | Without Inserts•       | Yes                  | BW74YU          | BW74BU | BW74RU |
|              | Without Inserts        | Yes                  | BW80YU          | BW80BU | BW80RU |
|              | Up-Down                | Yes                  | BW82Y           | BW82B  | BW82R  |

• Maintained Contact

## > Put our expertise to work for you.

For more information on Schneider Electric push buttons and operator interface solutions, visit us online at [1-888-778-2733](tel:1-888-778-2733).

### Schneider Electric - North American Operating Division

1415 S. Roselle Road  
 Palatine, IL 60067  
 Tel: 847-397-2600  
 Fax: 847-925-7500



This document has been printed on recycled paper