## VMICPCI-7593 SINGLE-SLOT Pentium PROCESSOR-BASED SYSTEM SLOT CompactPCI CPU

- Single-slot Pentium processor-based CPU
- Special features for embedded applications include:
  - 16 Mbyte bootable flash on secondary IDE
  - Remote Ethernet booting using Lanworks Technologies, Inc.'s BootWare®
  - Three programmable 16-bit timers
  - 32 Kbyte of battery-backed SRAM
  - Software-selectable watchdog timer with reset
  - PMC mezzanine expansion site (IEEE-P1386 common mezzanine card standard, 5 V)
  - <u>VMISFT-9421</u> IOWorks generic device driver and other IOWorks family software
  - <u>VMISFT-7418</u> board support for VxWorks
- Standard features include:
  - 32-bit CompactPCI single-slot Pentium processor-based CPU 166 (classic), 200 MHz MMX, and 233 MHz MMX versions
     Required for Solaris
  - External (L2) cache 512 Kbyte synchronous burst SRAM
  - Up to 128 Mbyte SDRAM using 144-pin SODIMM DRAM
  - Two on-board Fast Ethernet controllers supporting 10BaseT and 100BaseTX
  - $\circ~$  On-board Ultra-IDE hard drive and

<b>Operating System</b>
Operating System
Windows NT

Driver Software IOWorks generic device driver (<u>VMISFT-9421</u>) CPU Software Support Products

<b>Operating System</b>	
VxWorks	

```
Driver Software
VxWorks BSP
(<u>VMISFT-7418</u>)
<u>CPU Software Support</u>
<u>Products</u>
```

Operating System Solaris

No Driver Software Required for Solaris

Operating System QNX

No Driver Software Required for QNX

Operating System

floppy drive controllers



No Driver Software

Required for Linux

- High-performance 16550-compatible serial port through J3
- Enhanced parallel port with ECP/EPP modes supported through J3
- PS/2-style keyboard and mouse ports on front panel
- Real-time clock and miniature speaker included

Ordering Options	Α	B	С	-	D	E	F
VMICPCI-7593 -			0	-			
<pre>A = Processor 0 = Not Used 1 = Reserved 2 = Reserved 3 = Reserved 4 = 200 MHz Pentium Processor 5 = Reserved 6 = Reserved 7 = 166 MHz Pentium Processor 8 = Reserved 9 = 233 MHz Pentium Processor</pre>	r						
<pre>B = DRAM Memory 0 = Reserved 1 = 8 Mbyte 2 = 16 Mbyte 3 = 32 Mbyte 4 = 64 Mbyte 5 = 128 Mbyte</pre>							
C = 0 (Option reserved for future ACCESSO							
Utility rear panel transition board.							